

| Adapter List | | | | | |
|---------------------|----------------------|------------|---------------|---|------------|
| Number | Description | Qty | Number | Description | Qty |
| 1 | N PLUG TO SMA JACK | 1 | 13 | BNC PLUG TO SMA JACK | 1 |
| 2 | N PLUG TO SMA PLUG | 1 | 14 | BNC PLUG TO SMA PLUG | 1 |
| 3 | N JACK TO SMA JACK | 1 | 15 | BNC JACK TO SMA JACK | 1 |
| 4 | N JACK TO SMA PLUG | 1 | 16 | BNC JACK TO SMA PLUG | 1 |
| 5 | UHF PLUG TO SMA JACK | 1 | 17 | F PLUG TO SMA JACK | 1 |
| 6 | UHF PLUG TO SMA PLUG | 1 | 18 | F PLUG TO SMA PLUG | 1 |
| 7 | UHF JACK TO SMA JACK | 1 | 19 | F JACK SMA JACK | 1 |
| 8 | UHF JACK TO SMA PLUG | 1 | 20 | F JACK SMA PLUG | 1 |
| 9 | TNC PLUG TO SMA JACK | 1 | 21 | SMA FEMALE TO SMA FEMALE | 1 |
| 10 | TNC PLUG TO SMA PLUG | 1 | 22 | SMA MALE TO SMA MALE | 1 |
| 11 | TNC JACK TO SMA JACK | 1 | 23 | SMA MALE TO SMA FEMALE | 1 |
| 12 | TNC JACK TO SMA PLUG | 1 | 24 | SMA MALE TO SMA FEMALE ELBOW ADAPTOR | 1 |